

## REPA-Uncoupler 83 200

H0 3L

### Scale H0, 3-Rail

- For couplings from Fleischmann or Märklin, Märklin look-alike and Roco short couplings
- For problem free retrofitting in H0 3-Rail tracks
- With drill template
- Reliable
- Noiseless
- Almost invisible
- Space requirement under the baseboard only 43 mm

### Installation Guide

First drill a 4.5mm hole in the centre of the track, best between two sleepers for the uncoupling shaft.

Then the REPA-Uncoupling magnet is screwed under the board so that the uncoupling shaft can move freely in the drill hole. That is very simple: when one pulls the uncoupling shaft it is removed from the solenoid with a strong pull and the 4.5mm drill is used in its place. For easier removal of the uncoupling shaft cut or file off a little of the hemispherical stop at the end.

The uncoupling shaft protruding above the track is cut off at the top of the sleeper or 1mm below when in its rest position.

Then the beam is pressed on but not too hard because the bobbin is meant for fine height adjustment.

Finally the beam is fixed parallel to the track.

 **Uhlenbrock Elektronik**

### Our contact Details: Service

In the event of a defect or failure send the unit together with the invoice and a short description of the fault back to us for repair.

### Hotline

We are available if you have any questions!

Your direct line to a technician: **0 20 45 - 85 83 27**  
Mon - Tue - Thu - Fri, 14:00-16:00 and Wed 16:00-18:00



Uhlenbrock Elektronik GmbH  
Mercatorstr. 6D-46244  
Bottrop  
Made in Germany

Electronic devices do not  
belong in household rubbish



**Part No. 83 200**